

Wiring Diagrams

CK-63 Oil Fired System Simultaneous Burner Wiring with Electronic Primary

POLARITY SENSITIVE

*L1 = Hot

*L2 = Neutral

WARNING: Reversed polarity may cause equipment damage!

----- New wire supplied by installer

⊃ Solderless connector (wire nut)

* L1 is 120V

* N is 120V Neutral

M is 120V if the motor is running

M2 is 120V if the motor is running

T1 is 120V if there is a call for heat

T2 is 120V Neutral

T3 is 120V if there is a call for heat

